

# Quick Tips



Easy Steps to Use the Features of Your DVR


# 930-5593

## How Do I Record a Program?


You can set a recording with just one touch of the remote.





>> While in the **Guide**,  highlight the program you wish to record and press **Record**.  A red dot appears in the **Program Information** window to indicate the program will be recorded.

>> While watching live TV, simply press **Record**.  A **Recording Started** notice appears to indicate recording has begun.

## How Do I Record a Series?

1. Highlight the TV series you want to record in the **Guide** and press **Record**  twice to view the Overlay screen.

2. Select the Create a **Series Recording**  icon and specify your recording options, such as the type of episode you want to record and how many episodes you want to save.

3. Select **Record**  to record the series with these options.



## How Do I Watch a Recording?

Press **List**  to view a list of your recorded programs.

Highlight a program and press **OK**.  Select the Play icon. 



## How Do I View a List of Programs Scheduled to Record?

1. Press **Menu** twice. 

2. Select **DVR**. Press **OK**.

3. Select **Future Recordings**. Press **OK**.



## How Do I Pause, Rewind, Forward & Instantly Replay Live TV?



Press Pause (**PAUSE**), Rewind (**REW**) Forward (**FFWD**) or Replay (**REPLAY**) on the remote.

## How Do I Play in Slow-Motion?




Press **Pause** , then press **Fast-Forward** to view slow-motion in forward mode. Or press **Pause** , then **Rewind** to view slow-motion in reverse mode.

## How Do I Return to Live TV?






Press **LIVE TV** on your remote.

## How Do I Change Channels when I am Watching a Show that I am Recording?

When you get a message saying that changing the channel will stop this recording, press the SWAP button to change tuners.  You may now watch another program without interrupting your recording.

*Unless you are Recording 2 Shows at the same time. You can swap between shows or you can watch previous recording under **LIST**.*

## How Do I Modify My Series/ Recordings Priority?

1. Press **Menu** twice. Select **DVR**.
2. Select **Future Recordings**. Press **OK**.
3. Highlight Series you want. Press Info Button 
4. Using Arrows to go Record icon. ● Press **OK**.
5. Select  Modify setting for this program only. Press **OK**
6. Use the arrows < >  to modify the priorities.

any questions  
please call  
or **930-5593**  
[www.tcaexpress.com](http://www.tcaexpress.com)

### Important Notes About Your DVR

- DVR is set to save programs until "Space is Needed." You can change the delete priority to "I Delete" for all programs or for individual programs.
- You can easily determine how much disk space is available by accessing DVR Recordings. The DVR #% Full indicates how much disk space is occupied.
- There is no limit to the number of future recordings you can schedule as long as you have available recording space.
- Think your Recording will run over its scheduled airtime. When you schedule a recording, adjust the End time of the program so that it is a few minutes past the scheduled airtime in Modify Recording.